

INSIGHTqc Software Upgrade Guideline Matrix

INSIGHTqc Software Upgrade Matrix		Upgrade from present version on controller								
		5.3.7	6.1.8	6.2.0	6.4.0	6.4.5	6.5.0	6.6.0	6.7.0	
To the desired version on controller	5.3.7	↓								
	6.1.8		↓							
	6.2.0		1. IRB OS Image 1.2.0 update 2. Reboot 3. IRB INSIGHTqc 6.2.0 update 4. Factory RESET - Yes							
	6.4.0		↓							
	6.4.5		↓	↓	↓	↓				
	6.5.0		SW Update: IRB Intermediate ver :6.5.0 Factory RESET : No Clear SATA : No	SW Update: IRB Intermediate ver :6.5.0 Factory RESET : No Clear SATA : No	SW Update:IRB Intermediate ver :6.5.0 Factory RESET : No Clear SATA : No	SW Update: IRB Intermediate ver :6.5.0 Factory RESET : No Clear SATA : No				
	6.6.0		↓	↓	↓	↓				
	6.7.0	↓	↓	↓	↓	↓	↓	↓	↓	
	6.8.5	1. Clear SATA : Yes 2. SW Update: USB v6.8.5 3. Factory RESET : Yes Intermediate ver :No	SW Update: IRB Intermediate ver :No Factory RESET : No Clear SATA : No	SW Update: IRB Intermediate ver :No Factory RESET : No Clear SATA : No	SW Update: IRB Intermediate ver :No Factory RESET : No Clear SATA : No	SW Update: IRB Intermediate ver :No Factory RESET : No Clear SATA : No	SW Update: IRB Intermediate ver :No Factory RESET : No Clear SATA : No	SW Update: IRB Intermediate ver :No Factory RESET : No Clear SATA : No	SW Update: IRB Intermediate ver :No Factory RESET : No Clear SATA : No	SW Update: IRB Intermediate ver :No Factory RESET : No Clear SATA : No

