


## Model 2100G Air Impact Wrench Exploded Diagram



(Dwg. TP2189-1)

### Model 2100G Air Impact Wrench Parts List

Item	Part Description	Part Number	Item	Part Description	Part Number
*	Housing Assembly	2100G-A40	*	Impact Mechanism Kit	2100G-IMK1
1	Housing	---	13	Hammer Case Gasket	---
3	Nameplate	---	14	Hammer (2)	---
4	Warning Label	---	15	Hammer Pin (2)	---
2	Screw, HammerCase (4 required)	2130-638	16	Anvil Assembly	---
3	Nameplate	2100G-300A	17	Hammer Frame	---
4	Warning Label	2100G-301A	*	Kit Grease	---
5	Power Regulator Assembly	2130-D249	18	Hammer Case Assembly	2130-D1727
6	Retaining Ring	2131-6	19	Trigger Assembly	2130-D1093
7	Ball Bearing (2 required)	402-22	20	Gasket	2130-283
8	Cylinder	2130-3	21	Reverse Valve Assy	2130-A329
9	Rotor	2131-53	22	Inlet Bushing Assy	2131-D565
10	Vane Pack (set of 6)	2131-42A-6	23	Reverse Button	2130-1075
11	End Plate	2131-11	*	Inlet Clip Removal Tool	2131-322
12	Rear Cap	2130-1012	*	Air Care Kit (grease gun, grease, oil)	115-LBK1
13	Hammer Case Gasket	2130-1036	*	Grease (replacement tube for -LBK1)	115-4T
			*	Air tool Oil (4oz. Bottle)	1024

\* Not Illustrated.



---

## Parts and Maintenance

When the life of the tool has expired, it is recommended that the tool be disassembled, degreased and parts be separated by material so that they can be recycled.

Tool repair and maintenance should only be carried out by an authorized Service Center.

Refer all communications to the nearest **Ingersoll Rand** Office or Distributor.

---

## Related Documentation

For additional information refer to:

Air Impact Wrench Product Safety Information Manual 04580916.

Air Impact Wrench Product Information Manual 04579736.

Manuals can be downloaded from [www.ingersollrandproducts.com](http://www.ingersollrandproducts.com).